

## CFX-750 Display: Upgrading Firmware

Before you upgrade the Trimble® CFX-750™ display you must do the following:

1. Save the display's current configuration to a USB drive.
2. Turn off the display.
3. Disconnect any devices that are plugged into Port A or Port B of the display.
4. When using the CenterPoint™ RTX™ correction service via satellite, write down the currently working satellite frequency and baud rate.

Once you have upgraded the firmware on the CFX-750 display, do the following:

1. Turn on the display.

Upgrade the firmware. The system will reboot automatically.

2. Reload the configuration from the USB drive where you saved it before upgrading the firmware.
3. Turn off the display.
4. Reconnect any devices that you disconnected before you upgraded the firmware.
5. When using the CenterPoint™ RTX™ correction service via satellite, go to the GPS Setup wizard and restore the settings that you wrote down earlier.

**This document is for informational purposes only and is not a legally binding agreement or offer.  
Trimble makes no warranties and assumes no obligations or liabilities hereunder.**

**Trimble Navigation Limited, AGRICULTURE Business Area, 10355 Westmoor Drive, Suite #100, Westminster, CO 80021, USA**

© 2013, Trimble Navigation Limited. All rights reserved. Trimble and the Globe & Triangle logo are trademarks of Trimble Navigation Limited, registered in the United States and in other countries. CenterPoint, CFX-750, and RTX are trademarks of Trimble Navigation Limited. All other trademarks are the property of their respective owners.

